



# Powerbank USB-C PD 20W 10000

Quick guide


420-58B




[www.sandberg.world](http://www.sandberg.world)

## Charge Powerbank

Charge by USB-C or Micro USB



Charging status display




Click the button to check the capacity of Powerbank



Fast charging

## Charge devices

Example of use





Support

<http://helpdesk.sandberg.world>

## Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at [www.sandberg.world/warranty](http://www.sandberg.world/warranty)

**5**  
Years  
Warranty



**Powerbank USB-C  
PD 20W 10000**

Capacity: 10000 mAh / 3.7V / 37 Wh Product weight: 250g

Micro USB input: 5V/2A, 9V/2A, 12V/1.5A

USB-C input: 12V/1.5A, 9V/2A, 5V/2A (18W max)

USB-C output: 5V/3A, 9V/2.22A, 12V/1.67A (20W max)

USB-A output 1+2: 5V/4.5A, 9V/2A, 12V/1.5A (22.5W max)

Item no. 420-58B

[www.sandberg.world](http://www.sandberg.world)

Sandberg A/S  
Bregnerødvej 133D,  
3460 Birkerød,  
Denmark



Made in China

**NOTE:** For optimal battery performance, we recommend fully discharging and recharging the power bank at least once every three months.

For information on handling electronic waste, see [www.sandberg.world/weee](http://www.sandberg.world/weee)

