


Car Jumpstarter TirePump 10000

Quick guide


421-21




Product overview



- 1. Power On/Off
- 2. Mode
- 3. + PSI
- 4. Pump
- 5. Unit BAR/PSI/KPA
- 6. Light
- 7. - PSI
- 8. Display
- 9. USB-C In
- 10. USB-A Out
- 11. Hose Socket
- 12. Jumpstart port



- 13. Clamp Indicator Light
- 14. Clamp -
- 15. Clamp +
- 16. Jumpstart plug
- 17. Boost Button



- 1. Battery level percentage / Pumping value display
- 2. Error indicator*
- 3. USB-A discharging
- 4. USB-C charging
- 5. Inflation unit
- 6. Inflation mode
- 7. Battery charge status



For air mattresses, inflatable toys, balloons etc.



Valve converter




For sports balls (footballs, basket balls etc.)


Error indicator*

Error message on screen	Cause	Error solution
 1	USB discharge over current	Turn off the output and wait for the fault to be cleared - Reinsert to restore
 2	USB discharge short circuit	Turn off the output and wait for the fault to be cleared - Reinsert to restore
 3	Sensor not detected	The air pump is running and the air pressure value is always displayed as 0
 4	High temperature protection for inflating	Take a 10 minute break before re-inflating
 5	Charge and discharge high temperature protection	Alarm disappears when temperature is decreased (charging temperature: 0 - 50°C, discharging temperature: -20 - 60°C)


Charge Powerbank




Charge devices




Check battery status




Jumpstart Instructions




1. Power on




2. Plug in jump cable





3. RED to (+), BLACK to (-)




4. Start engine




Go to 4



Go to 4










5. Remove cable




6. Done






• Max: Petrol 4.0T / Diesel 3.0T • Wait 1 minute between attempts • Stop after 3 failed attempts


Clamp Indicator Guide



Inflate a Tire

- 


Air hose
- 
- 
- 
- 
- 

Press  3 seconds to start
- 

Short press to off

Inflation modes	Pressure range
	26-51 PSI, 1.8-3.5 BAR, 180-350 KPA
	26-44 PSI, 1.8-3.0 BAR, 180-300 KPA
	30-65 PSI, 2.0-4.0 BAR, 210-450 KPA
	4-16 PSI, 0.27-1.1 BAR, 25-110 KPA
	0-150 PSI, 0-10.3 BAR, 20-999 KPA


Flashlight procedure




Press




3 seconds




Tap 1×



Tap 2×



Tap 3×



Tap 4×

Support

helpdesk.sandberg.world

Warranty

There is a five-year warranty on your Sandberg product.
Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty

5

Years
Warranty

Car Jumpstarter TirePump 10000

Item no. 421-21

Capacity: 10000 mAh / 37 Wh

Battery type: Lithium-ion

USB-C input: 5V/2A, 9V/2A, 12V/1.5A

USB-A output: 5V/2.4A

Clamp rated output: 12V DC 400A

Clamp peak output: 12V DC 800A

Air compressor pressure: Up to 150 PSI

LED light power: 2W

Product weight: 784g

www.sandberg.world info@sandberg.world
Sandberg A/S

Bregnerødvej 133D, 3460 Birkerød, Denmark



Made in China

NOTE: If not used regularly, please recharge the powerbank at least every 3 months to maintain optimal performance.

